

Function/Feature	DALI Device Type	5502DAL + DCDALCIP250-2	5502CDGP230	5500AC2	5500NAC2*
DALI ECG DT1 (Emergency or Exit Light (Generic))	ECG	X	✓	X	✓
DALI ECG DT1 A (Emergency or Exit Light (Switched Maintained Dimmable))		X	✓	X	✓
DALI ECG DT1 B (Emergency or Exit Light (Switched Maintained Non-Dimmable))		X	✓	X	✓
DALI ECG DT1 C (Emergency or Exit Light (Maintained))		X	✓	X	✓
DALI ECG DT1 D (Emergency or Exit Light (Non – Maintained Dimmable))		X	✓	X	✓
DALI ECG DT 6 (Single Channel LED Device)					
DALI 2x ECG DT 6 (DALI 2 Channel Device (DT6))					
DALI 3x ECG DT 6 (DALI 3 Channel Device (DT6))					
DALI 4x ECG DT 6 (DALI 4 Channel Device (DT6))					
DALI ECG (DALI ECG (Generic))					
DALI 2x ECG (DALI 2 Channel Device (Generic))					
DALI 3x ECG (DALI 3 Channel Device (Generic))					
DALI 4x ECG (DALI 4 Channel Device (Generic))					
DALI ECG DT8 (XXXX...confirm on basic feature set supported))		X	✓	✓	✓
DALI ECG DT8 (Single Channel Tunable / Color Controllable Device))		X	X	X	X

Notes

* 5500NAC2 supports testing, reporting and status of emergency & exit lights



Function/Feature	DALI Device Type	5502DAL + DCDALCIP250-2	5502CDGP230	5500AC2	5500NAC2*
Total Number of 18mm Modules		4 (5502DAL) 4 (DCDALCIP250-2)	6	6	6
DALI two-way mapping		Global Setting per line	Defined option for: • DALI Broadcast • DALI Group • DALI Short Address (Object Address)	Not required for mapping	Not required for mapping
Visual Indicators - for Line Status, Addressing, Missing Devices		✓	✓	X	Status displayed during function Test
Emergency & Exit Light Testing & Reporting - Function & Duration		X	✓	X	✓
DALI Power Supply		DALI-1	DALI-2 (Onboard)	Not Applicable	Not Applicable
DALI Groups (Line A & Line B)		16 DALI Groups per Line Broadcast Group per Line Off Group per Line	16 DALI Groups per Line 16 Virtual DALI Groups per Line Broadcast Group per Line	Not Applicable	Not Applicable
DALI Scenes		16 DALI Scenes per DALI Line	16 Broadcast Scenes or 16 Scenes per DALI Group	Not Applicable	Not Applicable
C-Bus Remote Override to DALI		Broadcast Only	Supported per DALI	Not Applicable	Not Applicable

Notes

* 5500NAC2 supports testing, reporting and status of emergency & exit lights

Disclaimer

© Copyright Schneider Electric (Australia) Pty Ltd, 2023. All rights reserved. This material is copyright under Australian and international laws. Except as permitted under the relevant law, no part of this work may be reproduced by any process without prior written permission of and acknowledgement to Schneider Electric (Australia) Pty Ltd.

The materials presented in this document are distributed by Schneider Electric (Australia) Pty Ltd as an information source only.

The information and data within this document is subject to change without notice.

Schneider Electric (Australia) Pty Ltd makes no claims, representations, or warranties about the completeness of any information contained in this publication.

Schneider Electric (Australia) Pty Ltd disclaim all responsibility and all liability to you or any other person for any loss, injury, damage, costs, expenses or compensation of any kind arising directly or indirectly in connection with any act or omission of Schneider Electric (Australia) Pty Ltd in relation to this course.

* All brand names, trademarks, and registered trademarks are the property of their respective owners

This content has ended.